



INSTALLATION MANUAL

Parts Included:	Qty.
(1) 7.5mm Barrel #BRPROB-01	2
(2) 15mm Barrel #BRPROB-02	2
(3) 21.5mm Center Ring #BRPROB-03MBK	2
(4) 1.9 PB Steel Lock Ring #BRPROB-05BK	2
(5) PB1.9 COMBAT Faceplate #BRPBF020	2
(6) PB1.9 COMBAT Faceplate #BRPBF020	2
(7) PB XT5 COMBAT Wheel Cap #BRPB-COMBAT	2
(8) XT504 Wheel Hub Adapters #BRXT504V2	2
(9) M2.5x6 Scale Screw #BRPROB-09	16
(10) M2.5 x 8 Socket Cap Screw #BRASCH2508	16
(11) M2x9 Scale Screw #BRPROB-06	40
(12) M2 x 8 Socket Cap Screw #BRPROB-07BK	40
(13) M2 x 10 Socket Cap Screw #BRASCH2010	10
(14) M2 x 14 Socket Cap Pilot Screw #BRASCH2014	6
(15) M4 Lock Nut #BRASNUTM4	2
(16) 7mm Thin-Walled Socket Adapter #BRT10045	2
(17) 2mm Tip Replacement #BRT1049/1	1
(18) 3mm Tip Replacement #BRPROB-17/1	1
(19) PB Driver Handle #BRPROB-22	1
(20) PB 3D Nylon Cap Tool	1
(21) PB Decal Sheet	1



■ 7.5mm Barrel
 ■ 15mm Barrel
 ■ Faceplate (5)
 ■ Faceplate (6)
 ■ Wheel Cap
 ■ Steel Lock Ring

WHEEL OFFSET (STANDARD WIDTH) W/ XT504 HUB



■ 7.5mm Barrel ■ 15mm Barrel ■ Faceplate (5) ■ Faceplate (6) ■ Wheel Cap ■ Steel Lock Ring